



Foam Tipped Applicator

Spiral pointed foam tip, static dissipative polypropylene handle



Description

This foam tipped applicator is produced with reticulated 100ppi foam. It is thermally welded to a static dissipative solid polypropylene shaft that has a pointed tip under the foam.

Dimensions

2.725" Overall Length (69.215 mm)

Tip

- 0.137" Dia. (3.50 mm)
- 0.787" Length (20.00 mm)

Handle

- 0.091" Dia. (2.30 mm)
- 2.657" Length (67.50 mm)

Qualities

- Medical grade foam
- Long pointed tip for precision cleaning of small parts
- Side spiral grooves trap and retain particulates
- Dissipative shaft safe for sensitive electronics
- ESD safe
- Lint and residue free
- Made in USA

Applications

- Safe for static sensitive components
- Used for applying adhesives, solvents, solutions or other fluxes
- Used in electronic and medical device manufacturing

Ref #	Packaging
1283-PF ESD Non-Sterile	20/50 (20 static dissipative reclosable poly bags per case, 50 swabs per bag)



Puritan[®]