



Foam Tipped Applicator

Extra long tip, glass filled polypropylene handle



Description

This foam tipped applicator is produced with reticulated 100ppi foam. It is thermally bonded to a rigid glass filled polypropylene shaft. Extra long bullet tip is excellent for extended reach cleaning.

Dimensions

3.260" Overall Length (82.8 mm)

Tip

- 0.160" Dia. (4.06 mm)
- 1.00" Length (25.4 mm)

Handle

- 0.100" Dia. (2.54 mm)
- 3.210" Length (81.53 mm)

Qualities

- Lint and residue free
- Soft and non-abrasive
- Can be used with IPA and DI water, or dry
- Extra long reach
- Pointed handle allows for dual use
- Made in USA

Applications

- Cleaning electronics and equipment
- Removing contaminants and residues

Ref #	Packaging
1622-PF	20/50 (20 bags per case, 50 swabs per bag)



Puritan®