



Knitted Polyester Tipped Swab

Half Round Tip, Delrin® Polypropylene Handle



- Lint-free, half-round tip

- Light Delrin® polypropylene handle

Description

This lint-free swab has a knitted polyester tip that is ultrasonically welded to a polypropylene handle. Ideal for fiber optics manufacturing or for use in critical environments.

Dimensions

2.688" Overall Length (68.275 mm)

Tip

- 0.125" Dia. (3.175 mm)
- 0.575" Length (14.605 mm)

Handle

- 0.09" Dia. (2.286 mm)
- 2.656 Length (67.462 mm)

Qualities

- Half-round tip
- Light, Delrin® polypropylene handle
- Wear-resistant handle
- Can be used with IPA, acetone, and other solvents
- Lint and residue free
- Low in NVR's
- Made in USA

Applications

- Removing residues and particulates
- Applying adhesives or other fluids
- Fiber optics component manufacturing
- Critical environment cleaning swab - dependable cleaning applicator

| Ref # | Packaging |
|---------------------|----------------------------------------------------------------|
| 3615 Non-sterile | 10/10 (10 resealable poly bags per case, 100 swabs per bag) |



Puritan®