



Knitted Polyester Tipped Swab

Round Tip, Delrin® Acetal Handle



Description

This lint-free swab has a round, knitted polyester tip that is ultrasonically welded to a Delrin® acetal handle. Perfect for removing epoxy residue in fiber optics manufacturing.

Dimensions

2.825" Overall Length (71.755 mm)

Tip

- 0.125" Dia. (3.175 mm)
- 0.406" Length (10.312 mm)

Handle

- 0.09" Dia. (2.286 mm)
- 2.825 Length (71.755 mm)

Qualities

- Symmetrical, round tip
- Ultrasonically welded to a Delrin® acetal handle
- Can be used with IPA, acetone, and other solvents
- Lint and residue free
- Low in NVR's
- Made in USA

Applications

- Removing residues and particulates
- Applying adhesives or other fluids
- Fiber optics component manufacturing
- Critical environment cleaning swab - dependable cleaning applicator

Ref #	Packaging
3625 Non-sterile	10/10 (10 resealable poly bags per case, 100 swabs per bag)



Puritan®